

DIP switch settings for the Mars 2000 Bill Acceptor

(The DIP switches are located on the side of the bill acceptor)

SETTING	SWITCHES
1 WAY	DIP 1 ON/DIP 2 OFF
2 WAY	DIP 1 OFF/DIP 2 ON
4 WAY	DIP 1 ON/DIP 2 ON
HIGH ACCEPTANCE	DIP 3 OFF
HIGH SECURITY	DIP 3 ON
*\$1	DIP 4 ON=ACCEPT/OFF=REJECT
*\$2	DIP 5 ON=ACCEPT/OFF=REJECT
*\$5	DIP 6 ON=ACCEPT/OFF=REJECT
1 PULSE PER DOLLAR	DIP 7 OFF
*4 PULSES PER DOLLAR	DIP 7 ON
ALWAYS ENABLE	DIP 8 OFF
HARNESS ENABLE	DIP 8 ON

* Recommended factory settings allow for acceptance of \$1, \$2 and \$5 bills at 4 pulses per dollar.

Setting the Coin-In Menu

Settings for the bill acceptor are controlled by the settings for Electronic Mech 2 (2E) in the Coin-In Menu screen.

To set the Coin-In Menu to provide a bonus credit for the use of a dollar, set the number of coins (for Electronic Mech 2) to "4" and set the number of credits to "5." This will provide 5 credits for each dollar entered. "Meter Pulses" can be set to "4" to record the amount of "coins" in the cashbox, or it can be set to "5" to record the number of credits played, depending on your individual need. An illustration of the coin-in menu set to offer 5 credits for a dollar, with the meter counting coins, is shown below.

See your owner's manual for complete operating instructions for the Coin-In Menu.

COIN INPUT	COINS	=	CREDITS	&	METER PULSES
1E	1		1		1
2E	4		5		4