

ATTENTION:

OBSERVE PRECAUTIONS FOR HANDLING ELECTROSTATIC DEVICES

Removal/Installation of Hard Drive - FORCE Upright Fusion/Fun Zone

Hard Drive Removal

1. Turn off and unplug the game.
2. Unlock and open the bezel.
Fun Zone games and Fusion games with electronic boxes only: Remove the 2 screws fastening the electronics box cover and move the cover aside.
3. Locate the hard drive. It will either be mounted to the electronics box cover or against the back wall of the game. Remove the 3 screws or standoffs (see Figure 1) securing the hard drive mounting bracket to the cover or the game, then remove the hard drive assembly until you're able to disconnect the hard drive power connector and hard drive ribbon cable.
4. Remove the 4 screws and shoulder washers fastening the hard drive to the mounting plate.

Hard Drive Installation

1. Fasten the new hard drive to the mounting plate with the 4 screws and shoulder washers.
2. Connect the power connector and ribbon cable to the hard drive, then fasten the hard drive assembly to the electronics box cover or the game with the 3 screws or standoffs. See Figure 1.
3. Close and lock the bezel.
Fun Zone games and Fusion games with electronic boxes only: Replace the electronics box cover and fasten it with the 2 screws.
4. Plug in and turn on the game.



FIGURE 1 - HARD DRIVE