

ATTENTION:

OBSERVE PRECAUTIONS FOR HANDLING ESD-SENSITIVE DEVICES

**Removal/Installation of Major Assemblies -
Ion eVo/eVo Walleto/Elite Edge/Megatouch Entertainer**

Power Supply Removal

1. Turn off and unplug the game.
2. Unlock and open the CPU section.
3. Unplug the IEC connector from the power supply. See Figure 1.




FIGURE 1 - OVERVIEW OF HARD DRIVE

4. Disconnect the wire connector nearest to the power supply.
5. Remove the 2 screws fastening the power supply and mounting bracket to the game (Figure 2).



FIGURE 2 - POWER SUPPLY MOUNTING SCREWS (2 PLACES)

6. Remove the power supply.

ATTENTION:

OBSERVE PRECAUTIONS FOR HANDLING ESD-SENSITIVE DEVICES

**Removal/Installation of Major Assemblies -
Ion eVo/eVo Walleto/Elite Edge/Megatouch Entertainer (cont'd)**

Power Supply Installation

1. Install the new power supply and bracket in the game and fasten them with the 2 screws that were used to fasten the old power supply and bracket. See Figure 2.
2. Connect the power supply wire connection.
3. Reconnect the IEC connector to the power supply. See Figure 1.
4. Close and lock the CPU section.
5. Plug in and turn on the game.