

AMI Entertainment Network

Troubleshooting Guide for *Megatouch MAXX games*

PROBLEM	CORRECTIVE ACTION
<ul style="list-style-type: none">• game will not download CD	<ul style="list-style-type: none">• Make sure the CD is installed correctly, with the logo facing up.• Check for scratches or a defective disc.• Try a different set of CDs.• If you're downloading a CD set, make sure each disc is of the same revision.