

ATTENTION:

OBSERVE PRECAUTIONS FOR HANDLING ELECTROSTATIC DEVICES

Removal/Installation of Power Supply - Mr. VIPS

Power Supply Removal

1. Turn off and unplug the game.
2. Unlock and remove the rear door.
3. Unplug the IEC connector from the power supply.
4. Disconnect all connections to the main power supply harness.
5. If the power supply is fastened to the game with a metal strap (see Figure 1) and double-sided tape, remove the 2 screws fastening the strap, then carefully pull the power supply off the double-sided tape and out of the game. For games without the metal strap, remove the 2 screws fastening the power supply to the game (see Figures 2 and 3).

Power Supply Installation

1. Install the new power supply in the game in the same manner as the old power supply and fasten it with the existing hardware. If applicable, use double-sided tape to ensure the power supply is firmly held in place.
2. Reconnect all connections to the main power supply harness.
3. Plug the IEC connector into the new power supply.
4. Replace and lock the rear door.
5. Plug in and turn on the game.



FIGURE 1 - CLOSEUP OF POWER SUPPLY WITH METAL STRAP




FIGURE 2 - CLOSEUP OF POWER SUPPLY WITHOUT METAL STRAP



FIGURE 3 - CLOSEUP OF LEFT REAR BRACKET AND SCREWS
RIGHT FRONT SCREWS ARE LOCATED DIAGONALLY (SEE FIGURE 2)